

Specification Sheet

VIAVI 8800SX

Digital Radio Test Set



User Interface				
D: :	13.50 in (W) x 11.5	54 in (L) x 5.75 in ([D)	
Dimensions	34.3 cm (W) x 29	34.3 cm (W) x 29.3 cm (L) x 14.6 cm (D)		
Display Size	30.5 cm (12 in)			
Weight	7.71 kg (17 lbs) Base Unit			
Internal Battery	2.5+ Hour at Full Backlight			
Rugged	30 G Shock, MIL-STD 28800F Class 3			
Direct Input Power	50 W Continuous, 125 W Cyclical			
In-Line Power Meter	500 W, 4% Accuracy			
Record & Playback	Digital Audio Quality			
Quick Presets	Ultra-Fast Test S	Ultra-Fast Test Setup		
Frequency Lists	Tx Frequency, Tx Level; Rx Frequency			
"Fast Stack"	Instant Access to	Multiple Meters		
Tracking Generator	VSWR, Return Loss, Distance-to-Fault, Tuning Duplexers			
LMR System Sup	port			
P25	P25 Phase II	DMR	NXDN™	
dPMR	ARIB T98	AM/FM	PTC	
RF Generator				
Port Input Prot	ection			
GEN Port	+20 dBm (Input Power Alarm Typical)			
T/R Port	+52 dBm CW (Ir	+52 dBm CW (Input Power Alarm Typical)		
T/R Port	>+90°C (Temper	>+90°C (Temperature Alarm Typical)		
Frequency				
Range	2 MHz to 1000 MHz <2 MHz to 100 kHz Usable Range			
Accuracy	Same as timebas	Same as timebase		
Range	1 Hz			

RF Generator (continued)		
Output Level		
Range	T/R Port: -50 to -125 dBm ANT Port: -30 to -90 dBm GEN Port: -5 to -65 dBm	
Accuracy	±2 dB; ±1.5 dB (Typ)	
Resolution	1 dB 0.1 dB (0 to -6 relative to selected level); HOLD ATTEN: ON	
Port VSWR		
ANT Port	<1.5:1 Typical	
GEN Port	<1.5:1 Typical	
T/R Port	<1.2:1	
SSB Phase Noise	-90 dBc/Hz at 20 kHz offset	
	-95 dBc/Hz at 1 GHz at 20 kHz offset, Typical	
Spurious	Harmonics: -30 dBc, -42 dBc Typical	
	Non-Harmonics: -40dBc, -50 dBc Typical (±20 kHz offset from carrier; 0 to 1 GHz)	
Residual FM	<20 Hz rms in 300 Hz to 3 kHz BW	
	<4 Hz rms, Typical <100 MHz	
	<6 Hz rms, Typical <800 MHz	
	<11 Hz rms, Typical >800 MHz	
Residual AM	<0.5% rms in 300 Hz to 3 kHz BW	

RF Generator Modulation

RF Generator Modulation Type	
Group	Modulation
Analog	None, FM and AM
Digital	P25 (C4FM, H-CPM, H-DQPSK), DMR, dPMR, ARIB T98, NXDN, PTC
DTMF	None, FM and AM
DCS	None, FM and AM
Two-Tone Sequential	None, FM and AM
Tone Remote	None, FM and AM
Tone Sequential	None, FM and AM

RF Generator Modulation (continued)

FM Modulation - Inte	rnal (GEN 1, GEN 2)
Modulation Frequency	/ Range
Range:	0 Hz to 20 kHz
Resolution:	0.1 Hz
Accuracy:	Timebase ±2 Hz
FM Deviation Range:	Off 0 Hz to 100 kHz (GEN 1 and GEN 2 Selectable)
Total Harmonic Distortion:	3% (1000 Hz rate, >2 kHz Deviation, 300 Hz - 3 kHz BP filter)
Resolution:	1 Hz
Accuracy:	±5% at 1 kHz rate; 2 kHz to 50 kHz deviation (±1% typical) ±10% at 150 Hz to 3 kHz rate; 2 kHz to 50 kHz deviation
FM Modulation - Exte	ernal (MIC, AUDIO IN)
Microphone In	
Alternate MIC Configurations	MIC Connector Pins
Range 1: 2-15 mVrms (8 mVrmw Typical)	Pin 2-OPEN, Pin 6-GND
Range 2: 35-350 mVrms (100 mVrms	Pine 2-GND, Pin 6-OPEN
Typical)	(Range 2 enables a nominal 3 Vdc Bias Voltage)
Range 3: 2-32 mVrms (20 mVrms Typical)	Pin 2-OPEN, Pin 6-OPEN
MIC Frequency Range	300 Hz to 3 kHz
MIC Level	Off, 0 Hz to 80 kHz
MIC Modulation Accuracy	±20% (300 Hz to 1.2 kHz) ±30% (>1.2 kHz)
MIC Slope	Positive voltage yields positive deviation
Audio In	
AUD IN Input	Range: 30 V, 3V
AUD IN Switchable Loads	3 V Range: 150 ohms, 600 ohms, 1K ohms, High Z 30 V Range: High Z
AUD IN Input Levels	3 V Range: 0.05 to 3.2 Vrms 30 V Range: 3 Vrms - 30 Vrms
AUD IN	300 Hz to 5 kHz
AUD IN	3 V Range: 1 kHz/35 mVrms Typical 30 V Range: 1 kHz/350 mVrms Typical
AUD IN	Positive voltage yields positive deviation
AM Modulation - Inte	rnal (GEN 1, GEN 2)
Modulation Frequency	/ Range
Range	0 Hz to 20 kHz
Resolution	0.1 Hz
Accuracy	Timebase ±2 Hz
Range	Off, 0 to 100% (GEN1 and GEN2 Selectable)
Resolution	0.1%
Total Harmonics Distortion	3% (20% to 90% mod, 1000 Hz rate, 300 Hz to 3 kHz BP filter)
Modulation Accuracy	10% setting, 150 Hz to 5 kHz rate 10% to 90% modulation

Microphone In		NIC C
Alternate MIC Config	•	MIC Connector Pins
Range 1: 2-15 mVrms (8 mVrms Typical)		Pin 2-OPEN, Pin 6-GND
Range 2: 35-350 mVrms (100 mVrms Typical)		Pin 2-GND, Pin 6-OPEN (Range 2 enables a nominal 3 Vdc bias voltage)
Range 3: 2-32 mVrms (20 mVrms Typical)		Pin 2-OPEN, Pin 6-GND
MIC Frequency Rang	е	300 Hz to 3 kHz
MIC Modulation		0% to 80%
MIC Modulation Accuarcy		±20% (300 Hz to 1.2 kHz) ±30% (>1.2 kHz)
Audio In		
AUD IN Input		Range: 30 V, 3 V
AUD IN Switchable Loads		3 V Range: 150 ohm, 600 ohms, 7 K ohms, High Z 30V Range: High Z
AUD IN Input Levels		3 V Range: 0.05 to 3.2 Vrms
		30 V Range: 3 Vrms - 30 Vrms
AUD IN AM Frequen	cy Range	300 Hz to 5 kHz
AUD IN Level Sensiti	vity	3 V Range: 1% / 35 mVrms Typica (High Z Load)
		30 V Range: 1% / 350 Vrms Typic (High Z Load)
AFGEN 1 and AFGE	N 2	
Frequency		
Range	0.0 Hz to	o 20.0 KHz
Resolution	0.1 kHz	
Accuracy	Timebas	e ±2 Hz
Outract Lavel		
Output Level		
Audio Out Port Impedance	<1 ohm	
Audio Out Port		to 1.57 Vrms
Audio Out Port Impedance		
Audio Out Port Impedance Audio Level Out	0 Vrms t	
Audio Out Port Impedance Audio Level Out Resolution	0 Vrms t 0.001 Vrr ±10%; >	ms
Audio Out Port Impedance Audio Level Out Resolution Accuracy	0 Vrms t 0.001 Vrr ±10%; >	ms 100 mVrms, 30 Hz to 3 kHz
Audio Out Port Impedance Audio Level Out Resolution Accuracy Distortion RF Receiver	0 Vrms t 0.001 Vrr ±10%; > <3% (1 k	ms 100 mVrms, 30 Hz to 3 kHz
Audio Out Port Impedance Audio Level Out Resolution Accuracy	0 Vrms t 0.001 Vrr ±10%; > <3% (1 k	ms 100 mVrms, 30 Hz to 3 kHz Hz rate, sine 300 Hz to 3 kHz)
Audio Out Port Impedance Audio Level Out Resolution Accuracy Distortion RF Receiver Port Input Protection	0 Vrms t 0.001 Vrr ±10%; > <3% (1 k	ms 100 mVrms, 30 Hz to 3 kHz Hz rate, sine 300 Hz to 3 kHz) n (Input Power Alarm Typical)
Audio Out Port Impedance Audio Level Out Resolution Accuracy Distortion RF Receiver Port Input Protection ANT Port	0 Vrms t 0.001 Vrm ±10%; >2 <3% (1 k -20 dBm +52 dBm	ms 100 mVrms, 30 Hz to 3 kHz Hz rate, sine 300 Hz to 3 kHz) n (Input Power Alarm Typical)
Audio Out Port Impedance Audio Level Out Resolution Accuracy Distortion RF Receiver Port Input Protection ANT Port T/R Port	0 Vrms t 0.001 Vrm ±10%; >2 <3% (1 k -20 dBm +52 dBm	ms 100 mVrms, 30 Hz to 3 kHz Hz rate, sine 300 Hz to 3 kHz) n (Input Power Alarm Typical)
Audio Out Port Impedance Audio Level Out Resolution Accuracy Distortion RF Receiver Port Input Protection ANT Port T/R Port	0 Vrms t 0.001 Vrr ±10%; > <3% (1 k 0n +20 dBm +52 dBm >+90°C	ms 100 mVrms, 30 Hz to 3 kHz Hz rate, sine 300 Hz to 3 kHz) n (Input Power Alarm Typical)
Audio Out Port Impedance Audio Level Out Resolution Accuracy Distortion RF Receiver Port Input Protection ANT Port T/R Port T/R Port Frequency	0 Vrms t 0.001 Vrr ±10%; > 2 <3% (1 k 000 +20 dBm +52 dBm >+90°C 2 MHz to <2 MHz	ms 100 mVrms, 30 Hz to 3 kHz Hz rate, sine 300 Hz to 3 kHz) In (Input Power Alarm Typical) In CW (Temperature Alarm Typical)

RF Receiver (continued)

Input Amplitude	
Sensitivity	ANT: -80 dBm, typical 10 dB SINAD (-110 dBm with preamp) T/R: -40 dBm, typical, 10 dB SINAD
Minimum Level Receiver Measurements	ANT: -60 dBm Preamp off, -80 dBm Preamp On, RF Error Meter T/R: -20 dBm Preamp Off, -40 dBm Preamp ON, RF Error Meter
DEMOD Meters	ANT: Distortion, SINAD, Modulation, AF Counter T/R: Modulation, Distortion, SINAD, AF Counter
Maximum Input Level Receiver	ANT: +10 dBm (Auto, Preamp off) T/R: +47 dBm CW, FM
Measurements Receiver Demodulatio	+41 dBm AM
	ARIB T98, NXDN, P25 (C4FM, H-CPM,
AM Modulation - Exte	rnal (MIC, AUDIO IN)
IF Bandwidth	FM: 5 kHz, 6.25 kHz, 8.33 kHz, 10 kHz, 12.5 kHz, 25 kHz, 30 kHz, 100 kHz, 300 kHz
	AM: 5 kHz, 6.25 kHz, 8.33 kHz, 10 kHz, 12.5 kHz, 25 kHz, 30 kHz
Audio Filters Bandwidth	FM: C-WT BP, CCITT BP, NONE, 15 kHz LP, 300 Hz LP, 300 Hz HP, 5 kHz LP, 300 Hz to 5 kHz BP, 300 Hz to 20 kHz BP, 3 kHz LP
	AM: C-WT BP, CCITT BP, NONE, 15 kHz LP, 0.3 kHz LP, 0.3 kHz HP, 5 kHz LP, 300 Hz to 5 kHz BP, 300 Hz to 3 kHz BP, 0.3 kHz to 20 kHz BP, 3 kHz LP
Audio Output, Level Sensitivity	FM: 3 Vrms/kHz Dev/IF BW (kHz, ±15%) AM: 7 mVrms/% AM, ±15%
LO EMISSIONS	<-50 dBc
RF Frequency Error Me	eter
Units	Hz, PPM
Range	±200 kHz, ±1000 PPM
Resolution	1 Hz
Accuracy	Timebase ±1 Hz
RSSI (Receive Signal St Receiver IF Bandwidth	trength Indicator) RF Power Within
Units	dBm, Watts, microWatts
Range	-120 dBm to +60 dBm
RF Level Range	T/R Port (preamp off): -50 dBm to +47 dBm ANT Port (preamp off): -90 dBm to +10 dBm ANT Port (preamp on): -110 dBm to -10 dBm
Resolution	0.01 dBm
	<u> </u>
Accuracy	±3 dB; (1.5 Typical) Normalized

RF Power Meter (Broa	dband RF Power Into T/R Port)	
	50 Watts continuous, +25°C, ±10°C	
Maximum Input Level	125 Watts Cyclical (Max "ON" of 30 sec and Min "OFF" for 90 sec) for power levels >50 Watts	
Alarms	+49 dBm (Input RF Power Alarm) >+90°C (+194°F) (Temperature Alarm)	
Meter Range	+20 to +53 dBm	
Meter Floor	0.10 W/+20 dBm	
Averaging Range	1 to 99	
Display Units	Watts, dBm	
Resolution	0.01 W, 0.1 dBm	
Accuracy	10% of reading, (6% Typical)	
Ext Attenuation	-50 to +50 dB, 0.01 dB resolution	
FM Deviation Meter		
Range	500 Hz to ±100 kHz	
Meter Type	Peak+, Peak-, (Peak-Peak)/2, RMS	
Resolution	0.1 Hz	
Accuracy	±10% of reading, 500 Hz to 100 kHz	
	Deviation ±5% of reading, 1 kHz to 10 kHz Deviation	
	(150 Hz to 1 kHz rate)	
	±3% of reading, 1 kHz to 10 kHz Deviation (1 kHz to 1.5 kHz rate)	
AM Percent Meter	,	
Range	5% to 100%	
Modes	Peak+, Peak-, (Peak-Peak)/2, RMS	
Resolution	0.001%	
Accuracy	±5% of reading, 1 kHz rate 30% to 90% modulation, 3 kHz LPF	
SINAD Meter		
Measurement Sources	AUD IN, Demod	
DEMOD	FM: >2 kHz Deviation (IF BW set appropriately for received modulation BW) AM: >25% Modulation (IF BW set appropriately for received modulation BW)	
AUDIO IN Port		
Frequency Range	300 Hz to 10 kHz	
Input Level	3 V (Audio Config setup): 0.9 Vp-p to 9 Vp-p 30 V (Audio Config setup): 9 Vp-p to 90 Vp-p	
Audio Frequency Notch	1 kHz	
Reading Range	0 dB to 60 dB	
Resolution	0.001 dB	
Accuracy	±1.5 dB, reading >8 dB, <40 dB	

Distortion Meter	T
Measurement Sources	AUD IN, Demod
DEMOD	FM: >2 kHz Deviation (IF BW set appropriately for received modulation BW)
	AM: >25% Modulation (IF BW set appropriately for received modulation BW)
Audio IN Port	
Frequency Range	300 Hz to 10 kHz
Input Level	3 V (Audio Config setup): 0.9 Vp-p to 9 Vp-p 30 V (Audio Config setup): 9 Vp-p to 90 Vp-p
Audio Frequency Notch	1 kHz
Reading Range	0% to 100%
Resolution	0.001%
Accuracy	±10% of reading +0.1% Distortion, >1% to <20%
Audio Frequency Coun	ter
Measurement Sources	AUD IN, Demod
DEMOD	FM: 15 Hz to 20 kHz Rate (IF BW set appropriately for received modulation BW)
	AM: 100 Hz to 10 kHz Rate (IF BW set appropriately for received modulation BW)
AUDIO IN PORT	
Frequency Range	300 Hz to 20 kHz
Input Level	3 V (Audio Config setup): 28 mVp-p to 9 Vp-p
	30 V (Audio Config setup): 280 mVp-p to 90 Vp-p
Frequency Range	15 Hz to 20 kHz
Resolution	0.1 Hz
Accuracy	±1 Hz
Audio Frequency Level	Meter
Measurement Sources	AUD IN, SCOPE
Input Range	
Aud In Range	3 V, 30 V
Scope Range	2 VDC, 40 VDC
Frequency Range	200 Hz to <5 kHz
Load Selection	
Scope	High Z
Aud In	3 V Input Range: High Z, 150 ohms, 600 ohms, 1 Kohms 30 V Input Range: 10 K

Input Level	
Aud In Port	3 V Range: 10 mV rms to 3.2 V rms 30 V Range: 1 V rms to 30 V rms
Scope Port	2.0 VDC Range: 10 mV rms to 1 V rms 40 VDC Range: 1 V rms to 28.28 V rms
Display Unit Resolution	Volts: 0.001 V mV: 0.001 mV dBuV: 0.001 dBuV dBm: 0.001 dBm Watts: 0.001 W
Accuracy	±5% AUD IN Port
P25 MEASUR	EMENTS
Modulation Fidelity	,
Range	0 to 10%
Resolution	0.1%
Accuracy	<5.0% of reading (2.5 to 10%)
Symbol Deviation	
Range	1620 to 1980 Hz
Resolution	0.1 Hz
Accuracy	±10 Hz (1620 to 1980 Hz)
Symbol Clock Error	
Range	±12 ppm
Resolution	0.01 ppm
Accuracy	1 ppm (±0.0048 Hz)
DMR MEASU	REMENTS
FSK Error	
Range	0 to 10%
Resolution	0.1%
Accuracy	<5.0% of reading (2.5 to 10%)
Symbol Deviation	
Range:	1745 to 2140 Hz
Resolution:	0.1 Hz
Accuracy:	±10 Hz
Symbol Clock Error	
Range:	±12 ppm
Resolution:	0.01 ppm
Accuracy:	±1 ppm (±0.0048 Hz)
Oscilloscope	
Source	SCOPE, AUD IN, Demod
Bandwidth	5 kHz
Input Impedance	1
Scope Input	2.0 V Range: 53 K ohm 40 V Range: 1 M ohm
Audio I/O Input	3 V Range: 150 ohm, 600 ohm, 1 k ohm High Z 30 V Range: 10 k ohm
- L	10 10 00 1010

Scope: AC, DC and GND Audio In: AC only FM Internal Demod: DC AM Internal Demod: AC

Coupling

/ertical Range	
Scope, Audio In	10 mV to 10 V-div in a 1, 2, 5 sequence
FM Internal Demodulation	0.1 kHz to 50 kHz/div in a 1, 2, 5 sequence
AM Internal Demodulation	5, 10, 20, 50%/div
Vertical Accuracy	10% of full scale (DC to 5 kHz)
Horizontal Sweep	0.5 ms/div to 0.1 sec/div
Horizontal Accuracy	3% of full scale
Trigger Type	Internal (Auto, Normal)
Trigger Level	Variable on vertical scale
Markers	Two markers Displays vertical measurement (Voltage, kHz, % modulation) Displays Delta in time between markers
Channel Analy	zer
Range	2 MHz to 1 GHz
Span	10 kHz to 5 MHz (1, 2, 5 steps)
Windows	Hanning, Flat Top, Rectangle
Vertical Scale	2, 5, 10, 15, 20 dB/div
Marker Bandwidth	1 kHz to 5 MHz (1, 2, 5 steps)
Marker Offset	±1 kHz to ±1/2 Span (1, 2, 5 steps)
Power Band Width (PdB) Accuracy	±3 dB typical (30 dB signl to noise)
Noise Floor	-123 dBm (preamp off) -140 dBm (preamp on) (span 100 kHz), typical
Digital Multimeter (D	MM)
AC/DC Voltmeter	
Range	200 mV, 2 V, 20 V, 200 V, 2000 V, Auto (150 VAC RMS to VDC MAX input, Category II)
Resolution	3.5 digits (2000 counts)
Accuracy	DC: ±1% FS ±1 count AC: ±5% FS ±1 count +25 mV
AC/DC Ammeter	
Range	200 mA, 2 A, 20 A, Auto (20 A range uses optional shunt connected to Voltmeter)
Maximum Open Circuit Input Voltage	30 V RMS referenced to COMMON or EARTH GROUND, Cateogry I
Resolution	3.5 digits (2000 counts)
Accuracy	DC: ±5% FS ±1 count AC: ±5% FS ±1 count
AC Volts Frequency Range	50 Hz to 10 kHz
Ohmeter	
Range	200 ohms, 2 k ohms, 20 k ohms, 200 k ohms, 2 M ohms, 20 M ohms, Auto
Resolution	3.5 digits (2000 counts)

In-Line Power Meter	
RF Measurement Type	Average Power, Peak, Burst, Crest, CCDF
Frequency Range	25 MHz to 1 GHz
Power Range	500 mW to 500 W Average 13.3 W to 1300 W Peak
Insertion VSWR	<1.05
Insertion Loss	<0.05 dB
Directivity	29 dB up to 50 MHz 30 dB from 51 to 1000 MHz
Average Power	
Average Forward Power Range	500 mV to 200 W Average
Peak/Average Ratio, Max	12 dB
Accuracy, Average Forward Power	±4% of reading +166 mW Maximum accuracy performance at 25°C (±10°C) (77°F ±50°F)
Return Loss	0 to 23 dB
VSWR	1.15 to 99.9
Burst Average Power	
Burst Average Power Range	13.5 W to 500 W Average
Burst Width	1 μs to 5 ms
Repetitions Rate Min	200 Hz
Duty Cycle (D)	0.001 to 1.0 (D=Burst Width/Period)
Accuracy, Burst Average Power	±6% of reading +0.116/D mW
Peak Envelope Power	
Peak Envelope Power Range	13.3 to 1300 W
Peak Envelope Power Accuracy	Burst width >200 μ s: $\pm 7\%$ of reading, ± 0.70 W 1 μ s <bur> 1 μs <bur> 1</bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur></bur>
Crest Factor	
Measurement Range	500 mW to 300 W, 13.3 W Minimum Peak
Accuracy, Crest Factor	Linear Sum of Peak and Average Power Accuracies
Complementary Cumu	lative Distribution Function (CCDF)
Measurement Range	0.1 to 100%
Threshold Measurement Range	13.5 to 500 W
Measurement Uncertainty	±0.2%
Level Set Accuracy	As Peak Envelope, Power Accuracy +2.0%
Speaker Output	
Speaker	On or OFF
Output	75 dBa min at 0.5 m, 600 to 1800 Hz, max volume Speaker disconnects when headphones installed.

T/R Connector Type: N-Type Female ANT Connector Type: N-Type Female GEN Connector Type: N-Type Female Scope Connector Type: BNC Female AUD IN Connector Type: BNC Female AUD OUT Connector Type: BNC Female Headphone Jack: 3.5 mm Jack USB Connectors (Qty 3) Type: USB Type A External 10 MHz Reference Input: BNC Female Ethernet Connector Type: RJ45 DC Power in Connector: 2-position 2.5 mm Jack GND Connector: Banana DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional)		
Timebase Temperature Stability	Volume Control	
Aging 0.5 ppm/First Year 0.3 ppm/After First Year 0.3 ppm/After First Year 0.3 ppm/After First Year Depth Processing Proc	Level Range	Scale 0 to 100
Aging 0.5 ppm/First Year 0.3 ppm/After First Year External 10 MHz Reference Input External Input Frequency Range 10 MHz ±150 Hz External Input Level -10 dBm to +10 dBm Max Input +15 dBm Freq-Flex (Externally Referenced Timebase Calibration) Input Frequency Range 2 MHz to 1000 MHz Reference Input Port 7/R: >-20 dBm Antenna: >-40 dBm Freq-Flex Accuracy <0.5 Hz from external source applied + Stability + Aging 8 Example: 10 MHz External Input, after Freq-Flex = ±0.5Hz to external input. 10 MHz ±0.5Hz = 0.05 ppm + Stability + Aging 9 I/O Connections T/R Connector Type: N-Type Female ANT Connector Type: N-Type Female 9 Scope Connector Type: N-Type Female 9 AUD IN Connector Type: BNC Female 9 AUD OUT Connector Type: BNC Female 9 AUD OUT Connector Type: BNC Female 9 External 10 MHz Reference Input: BNC Female 9 External 10 MHz Reference 10	Timebase	
External 10 MHz Reference Input External Input Frequency Range External Input Level Input Frequency Range External Input Level Input Frequency Range External Input Level Input Frequency Range Reference Input Port Input Frequency Range Reference Input Port Input Frequency Reference Input Port Input Frequency Range Reference Input Port Input Frequency Range Input Frequency Range Reference Input Range Reference Input Reference Remale Redence Input Range Reference	Temperature Stability	±0.15 ppm at -20° C to 70° C (-4°F to 158°F)
External Input Frequency Range External Input Level Anx Input Freq-Flex (Externally Referenced Timebase Calibration) Input Frequency Range 2 MHz to 1000 MHz Reference Input Port Freq-Flex Accuracy Freq-Flex Accuracy Example: 10 MHz External Input, after Freq-Flex = ±0.5Hz to external input. 10 MHz ±0.5Hz to external inp	Aging	
Frequency Range External Input Level Aux Input Freq-Flex (Externally Referenced Timebase Calibration) Input Frequency Range Reference Input Port Reference Input Port Freq-Flex Accuracy Example: 10 MHz External Input, after Freq-Flex = ±0.5Hz to external input. 10 MHz ±0.5Hz to 2005 ppm + Stability + Aging Example: 10 MHz External Input, after Freq-Flex = ±0.5Hz to external input. 10 MHz ±0.5Hz = 0.005 ppm + Stability + Aging I/O Connections T/R Connector Type: N-Type Female ANT Connector Type: N-Type Female ANT Connector Type: BNC Female AUD IN Connector Type: BNC Female AUD OUT Connector Type: BNC Female Headphone Jack: 3.5 mm Jack USB Connectors (Qty 3) Type: USB Type A External 10 MHz Reference Input: BNC Female Ethernet Connector Type: RJ45 DC Power in Connector: 2-position 2.5 mm Jack GND Connector: Banana DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	External 10 MHz Refe	rence Input
Has Input	•	10 MHz ±150 Hz
Freq-Flex (Externally Referenced Timebase Calibration) Input Frequency Range Reference Input Port Reference Input Port Freq-Flex Accuracy Co.5 Hz from external source applied + Stability + Aging Example: 10 MHz External Input, after Freq-Flex = ±0.5Hz to external input. 10 MHz ±0.5Hz = 0.05 ppm + Stability + Aging I/O Connections T/R Connector Type: N-Type Female ANT Connector Type: N-Type Female GEN Connector Type: N-Type Female Scope Connector Type: BNC Female AUD IN Connector Type: BNC Female AUD OUT Connector Type: BNC Female Headphone Jack: 3.5 mm Jack USB Connectors (Qty 3) Type: USB Type A External 10 MHz Reference Input: BNC Female Ethernet Connector Type: RJ45 DC Power in Connector: 2-position 2.5 mm Jack GND Connector: Banana DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Sleep Mode Red: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green: Battery at full charge	External Input Level	-10 dBm to +10 dBm
Input Frequency Range Reference Input Port T/R: >-20 dBm Antenna: >-40 dBm Freq-Flex Accuracy < 0.5 Hz from external source applied + Stability + Aging Example: 10 MHz External Input, after Freq-Flex = ±0.5Hz to external input. 10 MHz ±0.5Hz = 0.05 ppm + Stability + Aging I/O Connections T/R Connector Type: N-Type Female ANT Connector Type: N-Type Female GEN Connector Type: N-Type Female Scope Connector Type: BNC Female AUD IN Connector Type: BNC Female AUD OUT Connector Type: BNC Female Headphone Jack: 3.5 mm Jack USB Connectors (Qty 3) Type: USB Type A External 10 MHz Reference Input: BNC Female Ethernet Connector Type: RJ45 DC Power in Connector: 2-position 2.5 mm Jack GND Connector: Banana DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Sleep Mode Red: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	Max Input	+15 dBm
Reference Input Port T/R: >-20 dBm Antenna: >-40 dBm Freq-Flex Accuracy Stability + Aging Example: 10 MHz External Input, after Freq-Flex = ±0.5Hz to external input. 10 MHz ±0.5Hz = 0.05 ppm + Stability + Aging I/O Connections T/R Connector Type: N-Type Female ANT Connector Type: N-Type Female GEN Connector Type: N-Type Female GEN Connector Type: BNC Female AUD IN Connector Type: BNC Female AUD OUT Connector Type: BNC Female AUD OUT Connector Type: BNC Female Headphone Jack: 3.5 mm Jack USB Connectors (Qty 3) Type: USB Type A External 10 MHz Reference Input: BNC Female Ethernet Connector Type: RJ45 DC Power in Connector: 2-position 2.5 mm Jack GND Connector: Banana DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	Freq-Flex (Externally I	Referenced Timebase Calibration)
Freq-Flex Accuracy Freq-Flex Accuracy Freq-Flex Accuracy Stability + Aging Example: 10 MHz External Input, after Freq-Flex = ±0.5Hz to external input. 10 MHz ±0.5Hz = 0.05 ppm + Stability + Aging I/O Connections T/R Connector Type: N-Type Female ANT Connector Type: N-Type Female GEN Connector Type: N-Type Female GEN Connector Type: BNC Female AUD IN Connector Type: BNC Female AUD OUT Connector Type: BNC Female Headphone Jack: 3.5 mm Jack USB Connectors (Qty 3) Type: USB Type A External 10 MHz Reference Input: BNC Female Ethernet Connector Type: RJ45 DC Power in Connector: 2-position 2.5 mm Jack GND Connector: Banana DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge		2 MHz to 1000 MHz
Stability + Aging Example: 10 MHz External Input, after Freq-Flex = ±0.5Hz to external input. 10 MHz ±0.5	Reference Input Port	
I/O Connections T/R Connector Type: N-Type Female ANT Connector Type: N-Type Female GEN Connector Type: N-Type Female Scope Connector Type: BNC Female AUD IN Connector Type: BNC Female AUD OUT Connector Type: BNC Female Headphone Jack: 3.5 mm Jack USB Connectors (Qty 3) Type: USB Type A External 10 MHz Reference Input: BNC Female Ethernet Connector Type: RJ45 DC Power in Connector: 2-position 2.5 mm Jack GND Connector: Banana DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Sleep Mode Red: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	Freq-Flex Accuracy	· ·
T/R Connector Type: N-Type Female ANT Connector Type: N-Type Female GEN Connector Type: N-Type Female Scope Connector Type: BNC Female AUD IN Connector Type: BNC Female AUD OUT Connector Type: BNC Female Headphone Jack: 3.5 mm Jack USB Connectors (Qty 3) Type: USB Type A External 10 MHz Reference Input: BNC Female Ethernet Connector Type: RJ45 DC Power in Connector: 2-position 2.5 mm Jack GND Connector: Banana DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge		
ANT Connector Type: N-Type Female GEN Connector Type: N-Type Female Scope Connector Type: BNC Female AUD IN Connector Type: BNC Female AUD OUT Connector Type: BNC Female Headphone Jack: 3.5 mm Jack USB Connectors (Qty 3) Type: USB Type A External 10 MHz Reference Input: BNC Female Ethernet Connector Type: RJ45 DC Power in Connector: 2-position 2.5 mm Jack GND Connector: Banana DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	I/O Connections	
GEN Connector Type: N-Type Female Scope Connector Type: BNC Female AUD IN Connector Type: BNC Female AUD OUT Connector Type: BNC Female Headphone Jack: 3.5 mm Jack USB Connectors (Qty 3) Type: USB Type A External 10 MHz Reference Input: BNC Female Ethernet Connector Type: RJ45 DC Power in Connector: 2-position 2.5 mm Jack GND Connector: Banana DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	T/R Connector Type: N-	Type Female
Scope Connector Type: BNC Female AUD IN Connector Type: BNC Female AUD OUT Connector Type: BNC Female Headphone Jack: 3.5 mm Jack USB Connectors (Qty 3) Type: USB Type A External 10 MHz Reference Input: BNC Female Ethernet Connector Type: RJ45 DC Power in Connector: 2-position 2.5 mm Jack GND Connector: Banana DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	ANT Connector Type: N-	-Type Female
AUD IN Connector Type: BNC Female AUD OUT Connector Type: BNC Female Headphone Jack: 3.5 mm Jack USB Connectors (Qty 3) Type: USB Type A External 10 MHz Reference Input: BNC Female Ethernet Connector Type: RJ45 DC Power in Connector: 2-position 2.5 mm Jack GND Connector: Banana DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	GEN Connector Type: N	-Type Female
AUD OUT Connector Type: BNC Female Headphone Jack: 3.5 mm Jack USB Connectors (Qty 3) Type: USB Type A External 10 MHz Reference Input: BNC Female Ethernet Connector Type: RJ45 DC Power in Connector: 2-position 2.5 mm Jack GND Connector: Banana DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator	Scope Connector Type: I	BNC Female
Headphone Jack: 3.5 mm Jack USB Connectors (Qty 3) Type: USB Type A External 10 MHz Reference Input: BNC Female Ethernet Connector Type: RJ45 DC Power in Connector: 2-position 2.5 mm Jack GND Connector: Banana DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator	AUD IN Connector Type	: BNC Female
USB Connectors (Qty 3) Type: USB Type A External 10 MHz Reference Input: BNC Female Ethernet Connector Type: RJ45 DC Power in Connector: 2-position 2.5 mm Jack GND Connector: Banana DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Sleep Mode Red: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	AUD OUT Connector Ty	pe: BNC Female
External 10 MHz Reference Input: BNC Female Ethernet Connector Type: RJ45 DC Power in Connector: 2-position 2.5 mm Jack GND Connector: Banana DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	Headphone Jack: 3.5 mr	n Jack
Ethernet Connector Type: RJ45 DC Power in Connector: 2-position 2.5 mm Jack GND Connector: Banana DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Sleep Mode Red: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	USB Connectors (Qty 3)	Type: USB Type A
DC Power in Connector: 2-position 2.5 mm Jack GND Connector: Banana DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Sleep Mode Red: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	External 10 MHz Refere	nce Input: BNC Female
GND Connector: Banana DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Sleep Mode Red: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	Ethernet Connector Type: RJ45	
DMM (Qty 3): Banana (Optional) IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Sleep Mode Red: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	DC Power in Connector: 2-position 2.5 mm Jack	
IN (In-Line Power Meter): N-Type Female (Optional) OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Sleep Mode Red: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	GND Connector: Banana	
OUT (In-Line Power Meter): N-Type Female (Optional) Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Sleep Mode Red: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	DMM (Qty 3): Banana (0	Optional)
Front Panel Indicators SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Sleep Mode Red: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	IN (In-Line Power Meter	:): N-Type Female (Optional)
SYS Indicator Green: 88XX Power On/Awake Mode Blue: 88XX Sleep Mode Red: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	OUT (In-Line Power Me	ter): N-Type Female (Optional)
Blue: 88XX Sleep Mode Red: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	Front Panel Indicators	
Red: 88XX Shutting Down Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge	SYS Indicator	Green: 88XX Power On/Awake Mode
Green/Red Flashing: Battery Temperature >60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge		Blue: 88XX Sleep Mode
>60°C (>140°F) Green Flashing: Battery Life <5% BAT Indicator Green: Battery at full charge		Red: 88XX Shutting Down
BAT Indicator Green: Battery at full charge		, ,
, ,		Green Flashing: Battery Life <5%
Amber: Battery is charging	BAT Indicator	Green: Battery at full charge
		Amber: Battery is charging

Microph	one Connecto	or	
6 PIN MI	C CONNECTO	R	
Pin Number	Name		Characteristic
1	GROUND		
2	SPEAKER+	Output	75 dBa min at 0.5 m, 60 to 1800 Hz, max volume
3	PTT	Input	GND, open (with international)
4	Mic/Audio	Input	0 to 30 mVrms, voiced tone (whistle), 300 Hz to 3 kHz
5	MICSEL 1	GND, open with pullup	GND = 3 V DC bias (active Mic) and Mic audio gain of 2 Open = 0 V DC bias and Mic audio gain of 3
6	MICSEL 2	GND, open with pullup	
Enviro	nmental	/Physical	
Overall Dimensions		34.3 cm (W) x 29.3 cm (L) x 14.6 cm (D) 13.5 in (W), 11.54 in (L) x 5.75 in (D)	
Weight		17 lbs (No hardware options installed)	
Temperature		Storage: -40°C to +71°C (-40°F to +159.8°F) MIL-PRF-28800F, Class 3	
		Note: Battery must not be subjected to temperatures below -20° C, nor above +60° C	
8800S O	peration		
DC Operation		-20°C to +50°C (-4°F to 122°F)	
AC/DC Power Supply		See AC Input Power Section	
Battery Operation		-20°C to approximately +50°C ^{1,2} (-4°F to approximately +122°F)	
Relative	Humidity		
Operation		5 to 95%, tested in accordance with MIL- PRF-28800F, Class 3	
Altitude			
Battery Only Operation		4,600 m (MIL-PRF-28800F, Class 3)	
AC Power Supply Operation		3,048 m (MIL-PRF-28800F, Class 3)	
Shock, Fo	unctional		
Operation		30 G Shock (Functional Shock), tested in accordance with MIL-PRF-28800F, Class 3	
Vibratio	า		
Operation		5 to 500 Hz random vibrations, tested in accordance with MIL-PRF-28800F, Class 3	
Bench Ha	andling		
Operation		Tested in accordance with MIL-PRF-28800F, Class 3	

 $[\]ensuremath{\mathsf{1}}\xspace$ Battery operation over temperature based on actual temperature rise of battery and intrument usage

^{2:} Battery must not be subjected to temperature below -20° C nor above +60° C

Environmental/Physical (continued)

Compliance		
EMC		
Emissions and Immunity	MIL-PRF-28800F, Class 3 EN61326-1, Class A EN61000-3-2 EN61000-3-3	
Safety	UL 61018-1 EN61010-1 CSA C22.2 No 61010-1	
Reliability	20,000 hours at 25°C (77°F)	
AC Input Power (AC to	DC Converter/Charger Unit)	
AC Input Voltage Range	100 to 250 VAC, 3 A max., 47 Hz - 63 Hz	
AC Input Voltage Fluctuation	Less than 10% of the nominal input voltage	
Transient Overvoltage	According to Installation Category II	
Usage Environment	Indoor use, Maximum Relative Humidity 80% for temperatures up to 31°C (87.8°F) decreasing linearly to 50% RH at +40°C (104°F), Installation Category II, Pollution degree 2	
Operating Temperature	0°C to +40°C (32°F to 104°F)	
Storage Temperature	-20°C to +85°C (-4°F to +185°F)	
EMI	EN55022 Class B, EN61000-3-2, Class D	
Safety	UL 1950, CSA 22.2 No 234 and No 950, IEC 950/EN 60950	
DC Input Power		
Voltage Range	11 to 24 VDC	
Maximum Power	55 W, 65 W charging Optional Battery	
Typical Power	30 W	
Fused	5 A, 32 VDC, Type F	
Supplemental Items		
Battery Type	Lithium Ion (Li Ion) battery pack Note: Battery must not be subjected to temperatures below -20°C, nor above +60°C	
Battery Operation Tim	ne	
100% Backlight	2 1/2 hours typical	
Minimum Backlight (still viewable)	3 hours typical	
Battery Charge Time	4 hours Unit Power Off Typical	
	4 hours Unit Powered On Typical Note: Battery to be charged at temperatures between 0°C and +45°C (32°F and +113°F)	
	Charge dead battery (<10% capacity) for 20 minutes before operation on external DC power	



Contact Us +1 316 522 4981 AvComm.Sales@viavisolutions.com

To reach the VIAVI office nearest you, visit viavisolutions.com/contact

© 2019 VIAVI Solutions Inc. Product specifications and descriptions in this document are subject to change without notice. 8800SX-ss-rts-nse-ae 30187398 902 0119